

































Rev: 0	ASSEMBLY PART NUMBERS	Engineering Standards
Date: 1/11/99		ES-3.001
Approved:		Sheet No. 4 of 6

Table C - Plate Punch Codes

01 BR  TL	02 AR  TL	03 CR  TL	04 DR  TL
05 FR  TL	06 ER  TL	07 HR  TL	08 GR  TL
09 JR  TL	10 IR  TL	11 LR  TL	12 KR  TL
13 MR  TL	14 OR  TL	15 NR  TL	16 PR  TL

Rev: 0	ASSEMBLY PART NUMBERS	Engineering Standards
Date: 1/11/99		ES-3.001
Approved:		Sheet No. 5 of 6

21 ABR/EBR  AAL/EAL	22 AAR/EAR  ABL/EBL	23 ACR/ECR  ACL/ECL	24 ADR/EDR  ADL/EDL
25 AFR/EFR  AFL/EFL	26 AER/EER  AFL/EFL	27 AHR/EHR  AGL/EGL	28 AGR/EGR  AHL/EHL
29 AJR/EJR  AJL/EJL	30 AIR/EIR  AJL/EJL	31 ALR/ELR  AKL/EKL	32 AKR/EKR  ALL/ELL
33 AMR/EMR  AML/EML	34 AOR/EOR  ANL/ENL	35 ANR/ENR  AOL/EOL	36 APR/EPR  APL/EPL